



5626 WINDOW SCRAPER

玻璃清潔刮刀

- Special handle designed for easier grip when operation.
- Replaceable blade design to change the blade quickly and easily.
- Blade width: 40mm.



2526 3PCS WINDOW SCRAPERS

3PCS 玻璃清潔刀組

- To easily scrape off emblems and pasters.
- Hard plastic and poly razor blade prevent the surface from being damaged.
- Contents: Super scraper - 25261
10" super razor scraper - 25262
Replacement poly razor blades x 100pcs - 25263.



2502 GASKET SCRAPER

起子刮刀

- Removes dirt, carbon from block.



2511 DOOR UPHOLSTERY REMOVER

膠扣起子

- Well designed tool removes upholstery clips in just a few seconds.
- Place the tool under the edge of door panel & insert in fastener then pry up.



3004 TRIM CLIP PLIERS

膠扣鉗

- Removes and saves all types of clips.
- The front of the tools is tapered will fit easily under a clip, spread the jaws lightly so they will go under and around the clip. Then, close the jaws and the clip saver removes the clip without damaging to the clip.
- Great for removing door panels.



3223 CLIP REMOVAL PLIERS

下壓式膠扣鉗

- Use the head of the pliers to inset the plastic button of the plate. Then push the tool and remove the plastic button.
- It is save manpower with pull straight.



3533 35° TRIM CLIP PLIERS

35 膠扣鉗

- Special designed 35° clipper to use in deep space.

